

User Manual for Matrix Maker

Version 2.3

I. Program Installation

To install the program, run the Setup.exe file.

The default folder for installation is

“C:\Program Files\Matrix Maker\Programmable Keyboard”.

II. Driver Setup

This section is only for Windows 2000 or XP users.

The default folder for the driver files is “C:\Program Files\Matrix Maker\KB Driver”. For the detailed instructions, please refer to the file, POSKB_DRV_SETUP.pdf, which is in the default folder.


III. Keyboard Programming Software

The default location of executable file is

“C:\Program Files\Matrix Maker\Programmable Keyboard\MatrixMaker.exe”

1. Select a keyboard

When the program runs, the Keyboard Category dialogue will appear.



Select the category of the keyboard you want to program, and then press OK button. The following instructions are based on S78A model, but they can also be applied for other models.

2. Edit Key Map

(If a magnetic card reader is selected in the Keyboard Category dialogue, you can treat Header, Separator, and Suffix as buttons in the keyboard and program them by ‘Key Code’ and ‘ASCII code’ methods. For details, please refer to the Section 4.)